

# 50W FM Transmitter Kit



**WHAT IS IN THE PACKAGE:**

**1X TRANSMITTER**

**1X ANTENNA**

**1X CABLE**

**1X POWER LINE**

**1X AUDIO LINE**

**Website**

**Click here**



**Video Show**

**Click here**





This FM stereo transmitter, using advance modulation system and Phase Lock Loop to control a steady frequency when transmitting.

New invented low noise system is used to reduce the noise level during broadcasting time.

A digital stereo system is used and control the stereo separation at great condition.

With a high gain antenna ,it can easy broadcast anywhere you

want.Home,apartment,church,school,club,camping,backyard,resident village.

This Broadcast Package is plug and Play design, very easy to use , as you could see it at instant. so you really could enjoy the stereo transmitter!

**Sales:** Lisa Yang

**Email:** christine@rs-radio.com

**Mob/Whatsapp/Wechat:** +86 185 4126 1286

**Web:** [www.rs-radio.com](http://www.rs-radio.com)



## Product Description

Working Voltage	AC100V-AC260V
Working Current	< 1A
Frequency Range	87.5~108MHz
Frequency Stability	±10PPM
Frequency Stepping	100KHz
Environment temperature	-10°C~45°C
Output Impedance	50Ω
RF output power	0W~50W
Harmonic, clutter radiation	≤-60dB
Audio distortion	0.5%
Frequency Response	50Hz~15000Hz
Separation	≥35 dB
Input level	≤15 dBV
Frequency Modulation	±75KHZ
SNR	≥65dB
Size	345mm*480mm*45mm
Weight	6KG





1.The frequency can be adjusted by rotating knob left/right from 87.5MHz to 108MHz, the step is 100 KHz.



2.The RF power can be set by turning the knob left/right from 0~50/150/500/1000Watts. Step is 0.1W others step is 1W.



3.The volume can be adjusted by rotating left/right to increase/decrease. The volume range is 0-14.



4.Temperature/ SWR protection

**NOTE:**

Connect antenna first ,then connect the power supply.

otherwise, transmitter will be burned out.

>Select an unused FM station in your area ,adjust any FM Radio to the signal that your are broadcasting on.



## Easy installation steps



## Professional FM Transmitter



# Company Introduction



**ISO 9001:2008  
QUALITY CERTIFICATE**



**Radio Transmitter  
FCC Certificate**



**Radio Transmitter  
CE&RTTE Certificate**



## Payment and shipping

### Payment



- Standard payment terms: pay30% deposit in advance, 70% balance before shipment.
- Online trade assurance order, all is up to you.
- More payment terms could be provided (T/T, PAYPAL, western UNION)

### Shipping

- It take about 3-10 workdays to arrive your address by DHL , TNT, FXDEX.And it take about 25-35 workdays to arrive your address by sea.
- Professional goods shipping forwarder

